



Using FieldGenius 2005 with Bluetooth on an HP iPAQ 3115


- 1) Click Start > Settings > Connections > Bluetooth




- 2) On the Services tab, select Serial Port, and ensure it is enabled. Authorization and authentication will depend on settings in your Bluetooth instrument.




- 3) Press the "Advanced" button and note the Outbound COM Port. You will need to enter this in FieldGenius as the Data Collector port. Press OK



4) On the General tab, ensure that Bluetooth is ON. Press “Turn on” if it is not.



5) Press the Bluetooth Manager link to connect to your Bluetooth instrument.



6) In FieldGenius, enter the Outbound COM Port we got earlier as your Data Collector Port. All other communications settings will be the same as if you are connecting with a cable.

